

Decking: Installation & Operation

An integrated feature of the GearWagon 125 Camper (aka GearLode)



Decking consists of four panels that are design-fit for position along the base interior's molded ledging.

Modular design for compact storage. Two panels store on each side of trailer as shown.



Storage

Each panel is a different length, and is numbered 1 through 4. For best fit and access, follow the positioning described below:

Panels #1 and #2 store on driver side. Store panel 2, followed by panel 1 (so panel 1 is most accessible). Note how panel one's steel channel rests above panel 2 as shown.



Panels #3 and #4 store on passenger side. Store panel 4, followed by panel 3 (so panel 3 is most accessible). Note how panel three's steel channel rests above panel 4 as shown.

The decking's galvanized channel should face the sidewall of the trailer base and rest on the molded deck ledge with the upper panel's channel resting on the lower panel's channel. Pull retainer strap tight to prevent panels from shifting in transit.



Installation

The decking panels position sequentially beginning at the front with panel #1. Proceed as follows:

Loosen decking straps starting with panels 3 and 4 located on the passenger side. Move these two panels to the rear to make room for installation of panels 1 and 2.

Remove panels 1 and 2, then place them in their respective deck locations from the front of the trailer starting with panel 1.

Be sure to install correctly, as each panel's length is designed for its specific location in the sequence.

